

Mitsubishi Power Train Modules

Acronym	Module Name
BMU	Battery Management Unit
CMU1	cell monitoring unit 1
CMU10	cell monitoring unit 10
CMU11	cell monitoring unit 11
CMU12	cell monitoring unit 12
CMU2	cell monitoring unit 2
CMU3	cell monitoring unit 3
CMU4	cell monitoring unit 4
CMU5	cell monitoring unit 5
CMU6	cell monitoring unit 6
CMU7	cell monitoring unit 7
CMU8	cell monitoring unit 8
CMU9	cell monitoring unit 9
CVT	Continuous Variable Transmission
DC/DC Converter	DC/DC Converter
ECM	Engine Control Module
EV-ECU	Vehicle Integrated Controlling System
MCU	Motor Control Unit
MFI	Engine Control Module
OBC	On board chargers
Shift Lever	Shift Lever Control Module
TCM	Transmission Control Module
	Transmission Control Module(4 A/T)
	Transmission Control Module(5 A/T)
	Transmission Control Module(7P)
	Transmission Control Module(Sports)
	Transmission Control Module(W TCL)
	Transmission Control Module(W/O TC)
TC-SST	Twin-Clutch Sportronic Shift Transmiss

Mitsubishi Body Modules

Acronym	Module Name	SWS
A/C	Air Conditioning Control Module	Simplified Wiring System (Multiplexed)
	Air Conditioning Control Module (Aut	
	Air Conditioning Control Module (Man	Topstack
ACC/FCM		Topstack Control Module
	Adaptive Cruise Control and Forward	
AND		
	Audio Navi Display	
	Navigation system	
AUDIO		
	Audio Control Module	
	CD Audio	
	Display Audio	
COMP&HTR		
	COMP&HTR	
Cruise Control		
	Cruise Control	
	Cruise Control(Auto)	
	Cruise Control(Auto)/PDC	
Display		
	Display Module	
	Display Module (Center)	
ETACS		
	Electronic Time & Alarm Control System	
F.A.S.T./IMMO/K		
	Immobiliser/Keyless/TMPS	
HFM		
	Hands Free Module	
HVAC		
	Heat, Ventilation and Air Conditioning	
Immobiliser		
	Immobiliser	
Lane Keep		
	Lane departure warning	
LIN		
	LIN	
Meter		
	Meter Control Module	
MiEV Remote Sys		
	Remote System	
OCM		
	Occupant Classification Module	
OSS		
	Output Speed Sensor	
Power Gate		
	Electric Lift gate system	
SAS		
	Side Airbag Module	
Satellite Radio		
	Satellite Radio	
SRS		
	SRS Airbag Module	
	SRS Airbag Module(CAN)	
	SRS Airbag Module(Driver & Passenger)	
	SRS Airbag Module(Driver side)	
	SRS Airbag Module(Evolution)	
	SRS Airbag Module(ISO)	
	SRS Airbag Module(With side airbag)	
	SRS Airbag Module(Without side airbag)	

Mitsubishi Chassis Modules

Acronym	Module Name
4WD	Four Wheel Drive Module
4WS/Electric Pow	4WS/Electric Power Steering
4WS/EPS	4WS/Electric Power Steering
ABS	Anti-Lock Brake System
	Anti-Lock Brake System(Evolution)
	Anti-Lock Brake System(Ex.Evolution)
	Anti-Lock Brake System(With ASC)
	Anti-Lock Brake System(With BTCL)
	Anti-Lock Brake System(With TCL)
	Anti-Lock Brake System(Without ASC)
	Anti-Lock Brake System(Without BTCL)
	Anti-Lock Brake System(Without TCL)
ACD	Active Center Differential
ASC	Active Stability Control
ASTC	Active Skid and Traction Control
AWC	All Wheel Control
AWD	All Wheel Drive
AYC/ACD	Active Yaw Control/Active Center Diff
ECPS/4WS	4WS/Electric Power Steering
FCM	Front Control Module
HBB	Hydraulic Brake Booster
SAS	Steering Angle Sensor
SS4	Super Select 4WD
SS4/4WD	Super Select 4WD/4WD
TCL	Traction Control Module
TPMS	Tire Pressure Module