

Nissan Powertrain Actuators

Air Conditionng Compressor Relay
Air Inlet Flap
ALTERNATOR DUTY
COOLING FAN SPEED SENSOR
Diag Capteurs Temperature Diesel Particulate
DPF regeneration
Engine mount control
Exhaust Fuel Injector
Fuel Flow Solenoid Valve
Fuel Pressure Solenoid Valve
Heater Plug No.1 And No.2
Heater Plug No.3
Heater Plug No.4
High Pressure Circuit Leak Test
Idle Speed Setting Incrementation
Injector Cylinder 1
Injector Cylinder 2
Injector Cylinder 3
Injector Cylinder 4
Interface test
Preheater Relay
Prevention Of Electrical Consumers
Relais Pompe A Carburant
Static Test Of Actuators
Turbocharger Control Solenoid Valve

4WD

Bleeding Auxiliary
ETS Solenoid
ETS Solenoid Valve
Solenoid
Solenoid Left
Solenoid Right

AT

A - Axis Supply Pressure Solenoid Valve
B - Axis Supply Pressure Solenoid Valve
Clutch A Pressure Solenoid Valve
Clutch B Pressure Solenoid Valve
CVT Oil Cooler Fan Circuit
Line Pressure Solenoid Valve
Lubrication Flow - Rate Solenoid Valve
Pressure Control Solenoid A
Pressure Control Solenoid B
Pressure Control Solenoid C
Reverse Lamp Relay
Sequence Solenoid Valve
Shift Lock Solenoid
Shift Solenoid A
Shift Solenoid B
Shift Solenoid C
Shift Solenoid D

Shift Solenoid E
Shift Solenoid Valve 1
Shift Solenoid Valve 2
Shift Solenoid Valve 3
Shift Solenoid Valve 4
Starter Relay
TCM Relay

ECCS

2 Status Switch Fuel Pump Control Module
3 Status Switch Fuel Pump Control Module
AAC Valve Output Duty
AAC Valve Output Duty (B Company)
AAC Valve Output Step
Adjustable Duct Solenoid Output
Air - Fuel Ratio Correction Value
Air - Fuel Ratio Correction Value (B Company)
Air Bypass Valve Control Solenoid
Air Bypass Valve Solenoid
Air Conditioner Relay Output
Air fuel ratio revision value
Air Pump Relay
Alternator Control Duty
Alternator Duty Direction Value
Bias 2
Bias Solenoid
Boost pressure PWM command (gasoline)
C - SCV Target Step Position (Bank1)
C - SCV Target Step Position (Bank2)
C - VTC Target Angle /E - VTC Target Angle (Intal)
Canister Drain Cut Valve
Canister drain valve command (CONTI)
Check Valve Bypass Valve
Controlled thermostat
COOLANT CIRCUIT SWITCHING SOLENOID VALV
Coolant temperature
Cooling Fan Drive Duty Direction Value
C-SCV target step position (BANK1)
Cut Valve Full Operation
C-VTC target angle
C-VTC target angle/ Electromagnetic VTC target
C-VTC target angle/Electromagnetic VTC target
Delivery Cut Valve
Dig Cooling Fan Relay - RF RH
Dig Cooling Fan Relay - RF RL
Dig Homogenized Final Ignition Timing
Dig Power Balance
Dig Power Balance (Mode1)
Dig Power Balance (Mode3)
Dig Stoichiometric Amount Of Air For Electronic
DIG Stoichiometric Electrically Controlled EGR T
Dig Stratified Amount Of Air For Electronic Cont
DIG Stratified Electrically Controlled EGR Target
Dig Stratified Final Ignition Timing
Dig Stratified Final Injection Timing

Dig Variable Pressure Regulator
E - VTC Target Angle (Exhaust)
EGR Cut Solenoid
EGR Permissin Solenoid
EGR Solenoid
Electric control EGR target step position
Electronic Control EGR Taget Step Position
Electronic Control TCV Active Test(Both Op
Electronic Engine Mounting Motor Control
Engine Coolant Temperature
ETC low response correction minute flow r
EVAP CNT DUTY valve degree of an angle
Evaporation CNT Duty Valve Position
Evaporation leak diagnosis
Evaporator Cnt Duty Valve - Evpdty2
Evaporator Cnt Duty Valve Oper
Evaporator Leak Diagnosis
Evaporator Leak Mode8 Diagnosis
Evaporator Leak P1441 Diagnosis
Evaporator Leak Reduced Pressure Diagno
Fixed Ignition Timing
Four states change FPC
Fuel Cut Valve (Cylinder Side)
Fuel Pump Relay
Fuel Pump Relay 2
Fuel Pump Relay 3
Fuel return Valve
Fuel Temperature In Tank/S
Fuel temperature sensor in GAS tank
Gas pump command state (Gasoline)
Grille shutter Operation
Hydraulic Pressure Drive Fan Final Speed
Icon Cng Engine - Side Fuel Shut Off Valve -
Idling Target Rotation Adjustment
Ignition timing
Ignition Timing (B Company)
Ignition Timing Adjustment
Intake camshaft phaser PWM command
Intake Manifold Pressure/Ambient Pressur
Intake Manifold Pressure/Atmospheric Pre
Knocksken (Development Mode)
Leak Diagnosis 0.02 Inch Evaporation
LPG Air - Fuel Ratio Correction Value
LPG interception valve relay
Motor Fan Activate Duty
Oil Pressure Driving Fan Final Rotation Spe
Oil pressure rco command with monitool
On - Off Dc Motor Driving - Air Fluid Device
ON-OFF system air fluidized device on DC r
Power Balance
PRVR Solenoid
Radiator Drive Duty
Radiator fan hi out
Radiator fan high relay
Radiator fan low out
Radiator fan low relay

Radiator fan mid out
Radiator Fan Output High
Radiator Fan Output Low
Radiator Fan Output Middle
Radiator Fan Relay - RF RH
Radiator Fan Relay - RF RL
Rear O2 Sensor Diagnosis
Rear O2 Sensor Heater
Rear O2/S diagnosis
Residual Pressure Keep Valve
RF RH
RF RL
SCV Solenoid
Second Air Cut Solenoid
Secondary Air Cut Solenoid
Solenoid VTC Target Angle (Exhaust Side)
Sub Fuel Control Solenoid Valve
Sub Fuel Pump Relay
Supercharger clutch
Taget Step Position Of Electronic Control EGR
Tank Cut Valve
Target Bypass valve angle
Target Idle speed
Target Idling Revolutions
Target power generation voltage of alternator
Temperature (B Company)
The CNG Cylinder Fuel Shut Off Valve - Cngcv 1
Third O2 Sensor Diagnosis
Third O2 Sensor Heater
Throttle valve position setpoint
Variable Duct Solenoid Output
Variable Fuel Pressure FPCM
Variable Valve Lift and Timing Intake Exhaust S
Variable Valve Lift and Timing Solenoid Exhaust
Variable Valve Lift and Timing Solenoid Intake S
Variable Valve Lift and Timing Solenoid Valve
Variable Valve Lift and Timing Solenoid Valve (E
Variable Valve Lift and Timing Solenoid Valve (I
VIAS (solenoid/On-Off type DC motor)
VIAS2 solenoid
VTC Solenoid
VVT control solenoid (exhaust)
W/G
Water Temperature

ENGINE1

A/C Relay Output
Air Pump Relay
Alternator Duty Direction Value
Aternator Duty
Canister Control S/V
Canister Control Sol Valve1
Canister Control Sol Valve2
Canister Drain Cut S/V
Canister Drain cut Sol Valve
Canister Purg Cut S/V
Canister Purg Premission S/V
Coolant temperature
Cooling Fan 1

Cooling Fan 2
Cooling Fan 3
Cooling Fan High
Cooling Fan Low
CVBV S/V
Desulfuration 1
Desulfuration 2
DIG Power Balance
DIG Power Balance (Mode 1)
DIG Power Balance (Mode 3)
DIG Radiator fan relay High
DIG Radiator fan relay Low
DIG variable pressure regulator
E - VTC Target Angle (Exhaust)
EGR Control
EGR Control S/V
EGR Control Valve
EGR Cooler Bypass Valve
EGR cooler bypass valve control solenoid valve
EGR Cut Solenoid
EGR opening angle
EGR solenoid A
EGR solenoid B
EGR Vol Cont/V
EGR Vol Cont/V (Mode 1)
EGR Vol Cont/V (Mode 3)
EGRC Sol Valve
Electronic Control Tcv Active Test(Both Open Ar
Engine Coolant Temp
Engine Coolant Temp (Company B)
Engine Mounting
ETC opening angle
Evap System Close
Evaporator Leak P1441 Diagnosis
Evaporator Leak Reduced Pressure Diagnosis
FCV
FICD S/V
FPCM
Fuel cut valve CNG cylinder
Fuel cut valve CNG engine
Fuel Injection
Fuel injection timing
Fuel Pump
Fuel Pump Relay
Fuel Rail Pressure Control Valve
Fuel Temp Sensor
Fuel temperature
Fuel/T Temp Sensor
Glow control unit
Glow Relay
Glow relay 1
Glow relay 2
IACV Idle S/V
IACV/AACV Opening
IACV/AACV Opening Duty
IACV/AACV Opening Duty (Company B)
IACV/AACV Opening Step
Idling target injection amount
Idling target speed

Ignition timing
Ignition Timing #1
Ignition Timing #2
Ignition Timing #3
Ignition timing (Company B)
Ignition timing (Mode 1)
Ignition timing (Mode 3)
Ignition Timing Adjustment
Inj Timing
Injection Timing
Inspection Mode 1
Intake Duct Sol Valve
Intercooler fan relay
Intercooler water pump relay
Lpg Air - Fuel Ratio Correction Value
MAP/Baro S/V
MAP/BARO Sol Valve
P/REG Cont Sol Valve
Power Balance
Pressure Regulator
Pressure Regulator S/V
PSIRC S/V
Radiator fan output High
Radiator fan output Low
Radiator fan output Mid
Radiator fan relay (High)
Radiator fan relay (Low)
Radiator fan relay (Mid)
Radiator fan relay High
Radiator fan relay Low
Rear O2 Sensor Diagnosis
Rear O2 Sensor Heater
SCB/V CONT Solenoid Valve
SCV solenoid 1
SCV solenoid 2
Second Air Cut Solenoid
Service Regeneration
Swirl Cont Solenoid Valve
Swirl Control Valve(B1)
Swirl Control Valve(B2)
Target EGR step number
Target ETC Angle
Target Fan RPM
Target Idling Revolutions
TC Boost Control Actuator
Third O2 Sensor Diagnosis
Third O2 Sensor Heater
Throttle ON/OFF solenoid A
Throttle ON/OFF solenoid B
Throttle valve
TRG EGR/V ANGLE
Turbo Charger boost control solenoid valve
Turbo Charger cooling pump
V/T Assign Angle
Valve Timing Control S/V
Valve Timing Solenoid
Variable Valve Lift and Timing Solenoid Val
Variable Valve Lift and Timing Solenoid Val
Variable Valve Lift and Timing Solenoid Val

VC/V Bypass Valve
VIAS Solenoid Valve
VVL S/V
W/G

ENGINE2

Canister Control S/V
Canister Drain Cut S/V
Canister Purg Cut S/V
Canister Purg Prepermission S/V
Cooling Fan High
Cooling Fan Low
CVBV S/V
EGR Control
EGR Control S/V
EGR Control Valve
Engine Coolant Temp
Engine Mounting
FICD S/V
Fuel Injection
Fuel Pump Relay
Fuel Temperature
IACV Idle S/V
IACV/AACV Opening
MAP/Baro S/V
Power Balance
Pressure Regulator S/V
PSIRC S/V
Valve Timing Control S/V
VVL S/V

HCM

Compression Test
Cooling Fan Speed
DC/DC Converter
Inspection Mode 2
INV Water Pump

HV

Engine Cranking
Inspection Mode 1
Inspection Mode 2
Inspection Mode 3
Inspection Mode 4
Inspection Mode 5
Voltage Control
Water Pump

LBC

Battery Relay
FAN rotation Active test for battery cooling.
Heater Relay
Heating Relay Active Test for Dealer

VCM

A / C Relay

Battery J / B Charging Relay
Battery J / B Main Relay (-)
Battery J / B Main Relay (+)
Charge Stat Indicator 1
Charge Stat Indicator 2
Charge Stat Indicator 3
Charging Port Lock Request
Cooling Fan
Dc / Dc Converter Warning Light
DC/DC Conv W/L
DC/DC Converter Duty
Discharge Ac-Inv
Discharge Indicator (Main For Sw)
Discharge Indicator (Meter)
Discharge Relay
ECO Indicator
ECO TREE
EV System W/L
Ev System Warning Light
F / C Relay
F / S Chg Relay
F/S Charge Relay
High Voltage Authentication Operation Comma
High Voltage Authentication Operation Comma
M / C Relay
Movable Indicator Light
Output Limit Indicator Light
Plug In Indicator
Plug-In Indicator Light
Power Limitation Indicator
Ready Indicator
Remaining Battery Capacity
Reverse Lamp Relay
State Of Charge Indicator 1
State Of Charge Indicator 2
State Of Charge Indicator 3
Variable Voltage
Voltage Control
Water Pump 1
Water Pump 2

Nissan Body Actuators

ACC

Accelerator Pedal Actuator
Booster Solenoid Valve
Camera Optical Axis Adjustment
Check The Amount Of Optical Axis Misalignmen
Check The Horizontal Axial Gaps
Check Vertical Axial Gaps
DCA Indicator
Fixed Flash Mode
Horizontal Target Optical Axis Adjustment
ICC Buzzer
Meter Lamp
Stop Lamp

ADAS

Active Pedal
Brake Actuator
BSI On Indicator
BSI Warning Indicator
BSW On Indicator
BSW/BSI Warning Lamp
Drive Mode Test
ICC Buzzer
Lane Departure Warning Lamp
LDP Buzzer
LDP On Indicator
LDP Warning Indicator
LDW On Indicator
LDW Warning Indicator
Meter Lamp
Stop Lamp
Warning System Indicator
YAW STEP L
YAW STEP R

ADP

Memory Switch Indicator
Mirror Motor Lh
Mirror Motor Rh
Pedal Motor
Seat Lifter
Seat Lifter Fr
Seat Lifter Rr
Seat Reclining
Seat Slide
Telesco Motor
Tilt Motor

AFS

Levelizer Test
LevelizerTest
Low Beam Test Left

Low Beam Test Right

ASD

Buzzer
Clutch
Look Release
Slide Door

AVM

AIR & Wash Active
AIR Active
AVM Buzzer
EPS working
External buzzer
LED LH Indicator
LED RH Indicator
Wash Active

BCM

A T Horn Test
A/C - Indicator Test
A/C Indicator - Heater Ventilation
ABD Test
ACC Cont
ACC Led Test
Acu Alarm Test
Air Pressure Monitor - Flasher Test
Air Pressure Monitor - Horn Chiap Test
Air Pressure Monitor - Run Flat Warn Buzzer Test
Air Pressure Monitor - TPMS Id Regist
Air Pressure Monitor - TPMS Id Registration Wa
Air Pressure Monitor - TPMS Lamp Warn Test
Air Pressure Monitor - TPMS Run Flat Lamp Wai
Air Pressure Monitor - TPMS Warn Lamp Test
Aircon Ind Test
All D/Lk MTR
All D/Un MTR
Anti Key Lock In Warn Test
Anti Theft Alarm - A T Horn Test
Anti Theft Alarm - Acu Alarm Test
Anti Theft Alarm - Flasher
Anti Theft Alarm - Flasher Test
Anti Theft Alarm - Head Lamp (Hi)
Anti Theft Alarm - High Beam Test
Anti Theft Alarm - Security Indicator Test
Anti Theft Alarm - Theft Indicator
Anti Theft Alarm - Vehicle Securityt Horn
As Seat Lamp Test
At Device Test
Auto Acc1/Ign Test
Auto Acc2 Test
Auto Retractable Mirror Test
Back Door Open Test
Battery Saver

Battery Saver - Room Lamp Battery Save T
Bcm - Horn Lamp Test
Brake Sw Test
Buzzer - Anti Key Lock Warn Test
Buzzer - Light On Warn Test
Buzzer - Reverse Warn Test
Buzzer - Run Flat Warn Buzzer Test
Buzzer - Seat Belt Warn Test
Buzzer - TPMS Id Registration Warn Test
Card Slot Illumi Test
Cdc Lock MTR
Cdc Unlock MTR
Chime
Cont St
Cont St Hev
Cornering Lamp Test
Door Handle Lamp Test
Door Lock
Door Lock - Back Door Open
Door Lock - Door Lock Indicator
Door Lock - Door Lock Indicator Test
Door Lock - Door Lock Test
Door Lock - Rr Def Test
Door Lock - Super Lock
Door Lock - Super Lock Test
Door Lock - Trunk/Back Door
Door Lock Ind Test
Door Lock Indicator Test
Door Lock Test
Door Lock Test(Jp)
Door Seat Lamp Test
Dr D/Lk MTR
Dr D/Un MTR
DTRL
Dtrl Test
Exterior Lamp Test
External Light - Cargo Lamp Test
External Light - Cornering Lamp
External Light - Cornering Lamp Test
External Light - Daytime Running Light
External Light - Dtrl (Daytime Running Ligh
External Light - Dtrl Test
External Light - Exiting Lamp Lh Test
External Light - Exiting Lamp Rh Test
External Light - Fr Fog Lamp
External Light - Fr Fog Lamp Test
External Light - Head Lamp
External Light - Head Lamp Test
External Light - Ill Dim Signal
External Light - L/D Judgement Test
External Light - Rr Fog Lamp
External Light - Rr Fog Lamp Test
External Light - Tail Lamp
External Light - Tail Lamp Test
Flasher
Flasher - Flasher

Flasher Left	Intelligent Key - Lcd Display In Meter Test	Ptc3 RI Test
Flasher Left(CAN)	Intelligent Key - Lock Led Test	Push Switch Indicator
Flasher Right	Intelligent Key - On Led Test	Rap - P/W Suply Rap Test
Flasher Right(CAN)	Intelligent Key - Outside Buzzer Test	Rap - Retained Pwr
Flasher Test	Intelligent Key - Power Indicator Test	Rear Defogger
Fr Fog Lamp	Intelligent Key - Room Lamp Battery Save Test	Rear Defogger Test
Fr Fog Lamp Test	Intelligent Key - Room Lamp Test	Retained Power
Fr Wiper Test	Intelligent Key Link (CAN)	Retained Power(IGN)
Fr Wiper(Hi)	Interior Lamp - Step Lamp Test	Retractable Mirror
Fr Wiper(Int)	Key Left Warn Test	Reverse Lamp Test
Fr Wiper(Low)	Key Reminder Warn	Reverse Warn
Fuel Lid Open	Keyfob P/W Test	Reverse Warn Test
Fuel Lid Open - Fuel Lid Open Test	Keyfob P/W Test(Up/Down)	Ring Sw Led Test
Head Lamp	L/D Judgement Test	Ring Switch Led Test
Head Lamp - Dtrl Test	LCD Display In Meter Test	Room Lamp Battery Save - Int Lamp
Head Lamp - Fr Fog Lamp Test	Light On Warn Test	Room Lamp Battery Save Test
Head Lamp - Head Lamp Test	Lock Acc On Led Test	Room Lamp Test
Head Lamp - L/D Judgement Test	Lock Led Test	Rr Def Test
Head Lamp - Rr Fog Lamp Test	Logical Lighting - Exiting Lamp Lh Test	Rr Fog Lamp
Head Lamp - Tail Lamp Test	Logical Lighting - Exiting Lamp Rh Test	Rr Fog Lamp Test
Head Lamp- Fr Fog Lamp Test	Logical Lighting - Int Lamp	Rr Wiper
Head Lamp Washer Test	Logical Lighting - Key Ring Lamp Test	Rr Wiper Test
Head Lamp Washer(CAN)	Logical Lighting - Luggage Lamp Test	Run Flat Warn Buzzer Test
Head Lamp(Hi)	Logical Lighting - Room Lamp	Seat Belt Warn Test
Head Lamp(Low)	Logical Lighting - Room Lamp Test	Security Ind Test
Head Lamp - Dtrl Test	Logical Lighting - Step Lamp Test	Securty Indicator
Heater Ventilation - Aircon Indicator Test	Mirror +5	Shiftlock Sorenoid Test
Horn	Mirror +5V Test	Signal Buffer - Brake Switch Test
Horn Chiap Test	Multi Remote Ent - Door Lock	Signal Buffer - Oil Pressure Switch Test
Horn Chirp Test	Multi Remote Ent - Door Lock Test	SI 12V CPU
Horn Lamp Test - Horn Lamp Test	Multi Remote Ent - Flasher	Smart Keyless - Door Lock
Ign Elec Cont Test	Multi Remote Ent - Horn	Smart Keyless - Flasher
IGN Illumination	Multi Remote Ent - Horn Chirp Test	Smart Keyless - Horn
Ign2 Cont Test	Multi Remote Ent - Int Lamp	Smart Keyless - Int Lamp
Ignition Cont1	Multi Remote Ent - Keyless P/W Test	Smart Keyless - Pbd
Ignition Cont2	Multi Remote Ent - Pbd	Smart Keyless - Power Slide Door
Ignition Relay	Multi Remote Ent - Power Slide Door	Smart Keyless - Pw Remoto Down Set
Ill Dim Signal	Multi Remote Ent - Psd Pbd Open Test	Smart Keyless - Trunk/Glass Hatch
Ill Dim Signal(CAN)	Multi Remote Ent - Psd Test	St Cont Low
Immu - Immo Indicator	Multi Remote Ent - Room Lamp Test	St Cut Cont Test
Immu - Security Indicator Test	Multi Remote Ent - Trunk Open Test	Step Lamp Test
Immu - Theft Indicator	Multi Remote Ent - Trunk/Glass Hatch	Stop Lamp1 Test
Immu Antenna	Non Dr D/Lk	Stop Lamp2 Test
Immu Power	Non Dr D/Un	Stop Lamp3 Test
Ind Led Test	Oil Pressure Switch	Super Lock Test
Inside Buzzer Test	Oil Pressure Test	Tail Lamp
INT Lamp	On Led Test	Theft Indicator
Int Lamp - Room Lamp Test	Outside Buzzer Test	TPMS - Flasher
Int Lamp - Step Lamp Test	Panic Alarm - A T Horn Test	TPMS - Flasher Test
Intelligent Key - ACC Led Test	Panic Alarm - Head Lamp(Hi)	TPMS - Flat Tire Warning
Intelligent Key - Asd Test	Panic Alarm - High Beam Test	TPMS - Horn Chirp Test
Intelligent Key - At Device Test	Panic Alarm - Panic Horn Test	TPMS - Id Regist
Intelligent Key - Auto Retractable Mirror Test	Panic Alarm - Trouble Lamp Test	TPMS - Id Regist Warning
Intelligent Key - Back Door Open Test	Panic Alarm - Vehicle Securityt Horn	TPMS - Run Flat Tire W/L
Intelligent Key - Flasher Test	Pas Seat Lamp Test	TPMS - Run Flat Warn Buzzer Test
Intelligent Key - Horn Chiap Test	Power Window Down	TPMS - Tpms Flat Tire Warn Test
Intelligent Key - I - Key Link Test	Ptc Heater	TPMS - TPMS Id Regist Warn Test
Intelligent Key - Indicator Led Test	Ptc1 RI Test	TPMS - TPMS Run Flat Lamp Warn Test
Intelligent Key - Inside Buzzer Test	Ptc2 RI Test	TPMS - Tpms Warn Lamp Test

TPMS - Warning Lamp

Tpms Id Registration Warn Test

Tpms Lamp Warn Test

Trouble Lamp Test - Trouble Lamp Test

Trunk Glass Hatch Open Test

Trunk Open - Trunk Open Test

Trunk Open - Trunk Relay Test

Trunk Open - Trunk Unlock Test

Trunk Open - Trunk/Glass Hatch

Trunk Output

Trunk/Luggage Lamp Test

Warning Buzzer - Anti Key Lock In Test

Warning Buzzer - Anti Key Lock Warn Test

Warning Buzzer - BACK DR OPEN WARN

Warning Buzzer - Door Warning

Warning Buzzer - DOOR WARNING IND

Warning Buzzer - Ign Key Warn Alm

Warning Buzzer - Key Left Warn

Warning Buzzer - Key Left Warn Test

Warning Buzzer - Key Reminder Warn

Warning Buzzer - Light On Warn

Warning Buzzer - Light On Warn Test

Warning Buzzer - Light Warn Alm

Warning Buzzer - Reverse Warn Test

Warning Buzzer - Reverse Warning

Warning Buzzer - Seat Belt Warn Test

Wiper - Fr Wiper

Wiper - Fr Wiper Test

Wiper - Head Lamp Washer

Wiper - Head Lamp Washer Test

Wiper - Rise Up Wiper Test

Wiper - Rr Wiper

Wiper - Rr Wiper Test

HLL2

Lamp Test

HSPL

Ambience Lamp

Engine Switch Illumination

Foot Lamp

Hospitality Light Illumination

Map Lamp - Assist Side

Map Lamp - Driver Side

Mood Lamp

Personal Lamp - Rear Left

Personal Lamp - Rear Right

Rear Defogger

HVAC

HVAC Test

HVAC Test - Step4 (Active Test)

Led All Segment Lighting

IAMP

Meter Illumination

ICON

Indicator

ITM

0 point adjustment

IVMS

Anti-Theft

Auto Drive Position

Auto Light

Auto Steering Position

Door Lock

Electronic Steering

Entry Key Illumination

Ign Key Ring Illumination

Ill Lampr

Inside Handle

Interior Illumination

Keyless Entry

Left Lights On

Locked-Out

Open Door Warning

Power Seat

Power Window

Rain Control Mirror Timer

Rear Defogger

Room Lamp Timer

Seat Belt

Seat Position

Step Lamp

Sunroof Relay

Trunk Opener S/V

Wiper

OBC

Normal Charge Relay -

Normal Charge Relay +

Quick Charge Parmit Sig Circuit

Quick Charge Relay -

Quick Charge Relay +

RCU

Buzzer, Audio, Trunk alarm

Flipper doors

Flipper doors latch motor

Hook

Parcel shelf rotation

Parcel shelf translation

Rear centre latch

Rear window defroster on

Roof

Trunk lid

Valve 1 on

Valve 2 on

Window Left And Right Front

Window Left Rear

Window Right Rear

RCU2

5th Bow System

Hydraulic Pressure Release

Inside Flap Motor

Outside Flap Motor

Power Window (Lh/Rh)

Rear Window Defogger

Roof Latched Lh/Rh

Roof State Output(Audio)

Roof System

Soft Top System

Storage LID

Storage LID Closure Motor

Trunk Opener

SMKEY2

ACC Indicator

At Devise

Card Slot Illumi

Door Lock Unlock

Ignition On Indicator

Indicator

Inside Buzzer

Key Lock Solenoid

LF Antenna

Liquid Crystal Display

Lock Indicator

Outside Buzzer

Ring Switch Led

SONAR

Buzzer

Cancel SW IND

Display Control

Front Buzzer

Led

Puddle Lamp

Rear Buzzer

Sonar Sensor

USM

AC Compressor

Compressor

Cooling fan (dual)

Cooling fan (mono)

Cooling fan (pulse width modulation)

Cornering Lamp

Daytime running light

External Lamps

Front fog lamp

Front wiper

Head Lamp

Head Lamp Washer

Headlamp (high)

Headlamp (low)

Headlamp washer

Horn

Lamps

Motor Fan

Optic axis active test

Parking lamp

Rear Defogger

Tail lamp

VSC

Start UP Sound Speaker

VSP Off Indicator

VSP Speaker

Nissan Chassis Actuators

Accelerator Pedal Actuator Test1
Accelerator Pedal Actuator Test2

4WAS

Lock Operation
Slow Mode

ABS

ABS Control Signal
ABS Motor
ABS Warning Lamp
ASCD Signal
Booster Drive
Booster Solenoid Driving
Decel G Sensor Calibration
Fr Lh Solenoid
FR LH ABS SOLENOID(ACT)
FR LH SOL
Fr Lh Solenoid
FR RH ABS SOLENOID(ACT)
FR RH SOL
FR RH Solenoid
Front Solenoid
Longitudinal G Sensor Calibration
Oil Pressure Generating Source
Rear Solenoid
REAR Solenoid
RR LH ABS SOLENOID(ACT)
RR LH SOL
Rr Lh Solenoid
RR RH ABS SOLENOID(ACT)
RR RH SOL
Rr Rh Solenoid
Slip Lamp
Solenoid (Actuator) FR LH ABS
Solenoid (Actuator) FR RH ABS
Solenoid (Actuator) RR LH ABS
Solenoid (Actuator) RR RH ABS
Solenoid Act Driving FR 2 Wheels
Solenoid Act Driving RR 2 Wheels
Solenoid Driving FR LH
Solenoid Driving FR RH
Solenoid Driving RR
Solenoid Driving RR LH
Solenoid Driving RR RH
Steering Angle Sensor Adjustment
Stop Lamp On Relay
TCS Fail Signal
TK ATST ABS Booster
Valve Calibration
VDC Warning Lamp

APA1

Accelerator Pedal Actuator Test 1
Accelerator Pedal Actuator Test 2

BSW

BSW/BSI Warning Lamp
ICC Buzzer

EACT

Stop lamp off relay

ECB

ABS Warning Lamp
Air Rel High Pres Line
Air Rel Inhibit
Air Rel Pwr Sply Sys 2
Air Rel Stroke Sim Sys
Air Rel Suc Drain Sys
Brake Warning Lamp
ELE Brake Warning Lamp
Main Relay 1
Main Relay 2
Motor Relay 1
Motor Relay 2
SCSS
Sla FL Sol
Sla FR Sol
Sla RL Sol
Sla RR Sol
Slip Indicator Lamp
Slr FL Sol
Slr FR Sol
Slr RL Sol
Slr RR Sol
Smc1
Smc2
VDC Warning Lamp
VSC HB Buzzer

EHS

Apply Both Actuators(Left-Right)
Brake Operation
Brake Release
Brake Test
Finish Brake Pad Replacement
G Sensor Calibration
Initialization Position Adjustment
Release Both Actuators(Left-Right)
Start Brake Pad Replacement
Switch On LED

HICAS

Self Diagnostic Mode

LDP

Buzzer Drive
Lane Departure Warning Lamp
LDP On Indicator
LDW On Indicator

LDW

Buzzer Drive
Lane Departure Warning Lamp
LDP On Indicator
LDW On Indicator

RADAR

Adjust the optical axis horizontal target
Brake Actuator
CCD camera optical axis adjustment
Check the horizontal axis deviation
Check the optical axis shift amount
Command for Horizontal Alignment
Drive Mode Test
Emission mode fixed
ICC Buzzer
Meter Lamp
Radar Emission
Radar Emission for CONSULT
Verify the amount of vertical axial deviatio
Vertical Alignment2
Vertical Alignment3

S-ABS

Four Wheel Actuator
Front Left Actuator
Front Right Actuator
Mode Lamp
Rear Left Actuator
Rear Right Actuator

SOW(Left)

Right/Left Indicator Drive

SOW(Right)

Activate Operation
Deactivate Operation
Right/Left Indicator Drive

SUS_AIR_LEVEL

Adjust Height Initial

Clear Height Initial
Compressor On/Off
Exhaust Solenoid On/Off
Reset Vehicle Height Initial Value
Setting Initialize Completion Flag
Standard Height Level
Vehicle Height Initial Value
Vehicle Height Standard Position Forcing Return
Warning Lamp On/Off

TPMS

Buzzer
Flasher
Hazard Lamp
Horn
ID Regist Warning
Outside Buzzer
Run Flat/t Warn Buzzer
Warning Lamp